REV.2009.11.23

1172 SERIES

Advanced Remote Starters & Vehicle Security Systems

ULTRA START™

OWNER'S GUIDE

WARNING: NEVER USE AN AUTOMATIC TRANSMISSION STARTER IN A MANUAL TRANSMISSION VEHICLE

www.ultrastarters.com

Note: Some features may not be available on certain models.

FCC ID NOTICE

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions:
1. This device may not cause harmful interference, and
2.This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the part responsible for compliance void the user's authority to operate this devise.

QUICK VIEW CHART

BUTTON	BUTTON PRESS	HONKS / FLASH	SYSTEM FUNCTION
KEYLESS ENTRY	1 SECOND	1	LOCK DOORS
	1 SECOND	2	UNLOCK DOORS
	5 SECONDS	2	AUXILIARY #2 OUTPUT (TRUNK)

The Keyless Entry button will toggle from Lock to Unlock each time the button is pressed. Pressing and holding the Keyless Entry button will activate the AUX channel (Trunk release)

START	PRESS & RELEASE	1	ACTIVATES REMOTE STARTER
	PRESS & HOLD	2	TURN OFF REMOTE STARTER
	PRESS & RELEASE (RUNNING BY THE KEY)	2	ACTIVATES ENGINE IDLE MODE
	PRESS & RELEASE (RUNNING BY REMOTE)	2	ACTIVATES EXTENDED RUNTIME

HOLD FOR 3 SECONDS	ON	ENTER TIMER MODE

*THE PARK LIGHTS WILL TURN ON TO CONFIRM TIMER MODE. YOU NOW HAVE 30 SECONDS TO SELECT THE START INTERVAL.

PRESS KEYLESS	2	SELECTS 2 HOUR TIMER MODE
PRESS START	3	SELECTS 3 HOUR TIMER MODE
PRESS KEYLESS & START	4	SELECTS 4 HOUR TIMER MODE

HOLD FOR 3 SECONDS	2	EXIT TIMER MODE

*THE PARK LIGHTS WILL FLASH AND THE HORN WILL HONK TWICE TO CONFIRM TIMER MODE IS OFF.

QUICK VIEW CHART

SERVICE MODE / EMERGENCY OVERRIDE MODE

TO AVOID SERIOUS INJURY, this remote start system must be set into Service Mode before any under hood servicing is started. Service Mode will prevent the vehicle from starting while the vehicle is being serviced. It is the sole responsibility of the vehicle's owner to place the system into Service Mode. The manufacture accepts no responsibility for accidental starting of the vehicle while the vehicle is being serviced.

ACTIVATING VALET MODE / EMERGENCY OVERRIDE

Turn the Ignition Key ON
(Leaving the key ON)

Press and hold the Valet switch for 8 to 15 seconds
(Time depends on "Valet Settings" Program Option)

5 HONKS = OFF	REMOTE START DEACTIVATED

Note- The Lock, Unlock and Aux channel will still work while the system is in Service Mode. The LED's on the antenna will turn on solid to indicate that the system is deactivated.

DEACTIVATING VALET MODE / EMERGENCY OVERRIDE

Turn the Ignition Key ON
(Leaving the key ON)

Press and hold the Valet switch for 8 to 15 seconds
(Time depends on "Valet Settings" Program Option)

2 HONKS = ON	REMOTE START ACTIVATED

SYSTEM OPERATIONS

PRESS & RELEASE

REMOTE STARTER ACTIVATION

1. Press and release the START button on the remote transmitter one time.*
*Press twice if the system is programmed for Safety Start.
2. The park lights will flash and the horn (optional) will Honk once as confirmation.
3. The vehicle will remote start and the park lights will turn on and remain on while the vehicle is running under remote start**.

- If the remote start fails to start see the diagnostics chart at the back of the manual.

****DEFAULT RUNTIME OF THE SYSTEM IS 15 MINUTES.**

TURN KEY ON

KEY TAKEOVER

Once the vehicle is remote started and you wish to enter the vehicle to drive away you must preform the following steps.

1. Enter the vehicle then insert the key into the ignition switch.
2. Turn the key forward to the ON or RUN* position. (This is usually 2-3 key positions)
*Do not turn the key to the start position.
3. Step on the brake and the remote starter will turn off however the vehicle will continue to run because the key is on. If the key is not in the on position when the brake is pressed the remote starter and the vehicle will both shut off.**

** If the vehicle shuts down simply restart the engine with the key.

DO NOT TURN THE KEY TO THE START POSITION WHILE THE ENGINE IS RUNNING.

SYSTEM OPERATIONS

PRESS & HOLD

REMOTE STARTER SHUT DOWN

1. While the vehicle is running with the remote starter press and hold the START button for three seconds.
2. The park lights will flash and the horn (optional) will honk 2 times to confirm shutdown.
- Pressing the brake pedal or opening the hood will also shut down the remote starter.

THE VEHICLE WILL SHUT OFF WHEN THE RUNTIME EXPIRES (DEFAULT

PRESS & RELEASE

ENGINE IDLE MODE

This feature allows the user to safely leave the vehicle running without leaving the keys in the ignition.

While the vehicle is running with the key press and release the START button then remove the key from the ignition. The vehicle will run for 15 minute while you are away. When re-entering the vehicle follow the key take over procedure.

PRESS & RELEASE

EXTENDED RUNTIME

1. While the vehicle is running with the remote starter, press and release the START button.
2. The park lights will flash and the horn (optional) will honk one time as confirmation. The system will reset the run time (See Example Below)**.
**Not available with 4 minute run time.

Example- If the vehicle has been remote started for 10 minutes and you press and release the start button the system will run for a addition 15 minutes totalling 25 minutes of runtime.

SYSTEM OPERATIONS

PRESS & RELEASE

UNLOCK DOORS

1. Press then release the Keyless Button on the remote transmitter.
2. The park lights will flash and the horn (optional) will honk two times.
3. The doors will unlock and the dome lights will activate. (optional)
4. The LEDs will stop flashing.

- The LEDs will be on solid if the system is in valet mode.

See Valet / Service Mode in this manual for further information
*** Optional Feature may require additional parts and labor.*

PRESS TWICE

DRIVER'S DOOR PRIORITY UNLOCK

Press the Keyless Button to unlock the drivers door. Press the Keyless Button again within 3 seconds to unlock the remaining doors*

*This is an optional feature that may not be available on all vehicles.

*** Optional Feature may require additional parts and labor.*

SYSTEM OPERATIONS

PRESS & RELEASE

LOCK DOORS

1. Press and release the Keyless Button on the remote transmitter.
2. The park lights will flash and the horn (optional) will Honk one time.
3. The doors will lock.
4. The LED will start flashing within five seconds.

See Valet / Service Mode in this manual for further information
*** Optional Feature may require additional parts and labor.*

Note-The LEDs can now be programmed not to flash when the doors are locked by the remote transmitter.

PRESS & HOLD

TRUNK RELEASE/ AUX 2 OUTPUT

1. Press then HOLD the Keyless Button on the remote transmitter.
2. The park lights will flash and the horn (optional) will honk two times.
3. The doors will unlock and then the trunk release will activate.

NOTES:
- For safety, the trunk release will not active when ignition key is ON.

*** Optional Feature may require additional parts and labor.*

1172 SERIES

OWNER'S MANUAL

Technical Support: support@ultrastarters.com

Additional Product Information: www.ultrastarters.com

IMPORTANT NOTES

LOCK, UNLOCK, DRIVER'S DOOR PRIORITY UNLOCK, TRUNK RELEASE AND THE AUXILIARY OUTPUTS ARE OPTIONAL OUTPUTS. ENABLING THESE FEATURES REQUIRES CUSTOM INSTALLATION & PROGRAMMING. THESE FEATURES MAY NOT BE COMPATIBLE WITH SOME VEHICLES.

FOR SAFETY REASONS THE TRUNK RELEASE OUTPUT WILL NOT ACTIVATE WHEN THE IGNITION IS IN THE ON POSITION.

NOTE: PADLOC AND 2ND CAR OPERATION ARE FEATURES THAT REQUIRE SPECIAL PROGRAMMING.

SOME FEATURES MAY NOT BE AVAILABLE FOR ALL APPLICATIONS. CONTACT YOUR DEALER FOR MORE INFORMATION.